


# Assembly Instructions

## SeaAira Adirondack Swing

**Tools Needed:** hammer, 7/16" wrench, #2 square bit screw driver or power driver, punch  
No drilling is required. All the necessary holes are predrilled. Bolts fit snugly in the holes. You may need to use a hammer to drive the bolts through the holes.




### Parts




### Step 2 – Fasten Arms to Seat

3½" Bolts, 2¾" Bolts, 1¾" Screws, Arm Assemblies



- A.** Push carriage bolts through the holes in the arm assembly. Use 3½" bolts for the front and 2¾" bolts for the back. Tap the bolt heads with a hammer to set them firmly against the leg. Place the nuts on the bolts and tighten securely.
- B.** Place three 1¾" screws in the pilot holes of the back crosspiece to secure it to the back of the arm.
- C.** Using a 1¾" screw, fasten the brace to the seat assembly.

### Step 1 – Fasten Seat to Back



### Step 3 – Fasten the Chain

2 Sets of Chain



Fasten the shortest length of chain to the eye bolt in the back. Fasten the second longest chain to the eye bolt in the seat.

Congratulations!  
Your SeaAira Adirondack  
swing is ready to enjoy!

